

HEATING BOILER LOG

NOTE: Should any check or test indicate that the device being tested or observed is not in good operating condition, it should be repaired immediately. Record repairs on the back so that a complete record will be available for review at any time.

MANUFACTURER: _____

BOILER NUMBER: _____

YEAR: _____

LOG THIS INFORMATION WEEKLY

MONTH	SAFETY/RELIEF VALVE TESTED					WATER COLUMN GAGE GLASS DRAINED					LOW WATER FUEL CUT - OFF TESTED					CIRCULATING PUMP/RETURN PUMP AND SYSTEM CHECKED					BURNER OPERATION CHECKED					
	WEEK					WEEK					WEEK					WEEK					WEEK					
	1	2	3	4	5	1	2	3	4	5	1	2	3	4	5	1	2	3	4	5	1	2	3	4	5	
JANUARY																										
FEBRUARY																										
MARCH																										
APRIL																										
MAY																										
JUNE																										
JULY																										
AUGUST																										
SEPTEMBER																										
OCTOBER																										
NOVEMBER																										
DECEMBER																										

TEST INSTRUCTIONS

SAFETY/RELIEF VALVE: Pull try-lever to full open position with pressure on the boiler. Release try-lever to allow the valve to snap closed. **Caution:** All discharges must be piped to a safe place.

WATER COLUMN OR GAGE GLASS: (steam systems only) - open the drain valve quickly to void a small quantity of water. Water level should return quickly when the drain valve is closed. **Caution:** All discharges must be piped to a safe place.

LOW WATER FUEL CUT-OFF: Drain float chamber while the boiler is running. This should interrupt the circuit and stop the burner. **Caution:** All discharges must be piped to a safe place.

PUMP AND SYSTEM: Check pump for proper operation and leaky packing. Examine traps, check valves, makeup float valves, expansion or condensate tank and other parts of the system.

BURNER OPERATION: If the burner starts with a puff or operates roughly, call your service personnel at once!

FOR IMMEDIATE REFERENCE, ENTER NAME, ADDRESS AND TELEPHONE OF YOUR SERVICE PERSONNEL

SERVICING

SERVICE DATES

LOW WATER FUEL CUT-OFF - The low water cut-off should be dismantled for a complete overhaul by competent service personnel at least annually. The internal and external mechanism, including linkage contacts, mercury bulbs, floats and wiring should be carefully checked for defects. See the manufacturer's instructions. Record the service dates above.

STOKER, OIL OR GAS BURNER AND CONTROLS - The stoker, oil or gas burner and all operating and protective controls should be thoroughly checked at least once every three months by a competent service organization. See the manufacturer's instructions. Record the service dates above.

The information contained in these materials is intended solely to provide general guidance on topics that may be of interest to you. While we have made reasonable efforts to present accurate and reliable information, Church Mutual Insurance Company, S.I. (a stock insurer)¹ and its affiliates expressly disclaim all liability for any errors or omissions, or for any actions you take or fail to take based on these materials. Links to any external websites provided in these materials are not maintained by Church Mutual Insurance Company, S.I. or its affiliates. Church Mutual Insurance Company, S.I. and its affiliates are not responsible for and do not in any way approve or endorse the content or accuracy of such sites. The information provided in these materials may not apply to your particular facts or circumstances; therefore, you should seek professional advice prior to relying on any information that may be found herein. © 2020 Church Mutual Insurance Company, S.I.. All Rights Reserved.

¹Church Mutual is a stock insurer whose policyholders are members of the parent mutual holding company formed on 1/1/20. S.I. = a stock insurer.